



SVENSKA	ENGLISH
Elschema, TS 120 A.	Wiring diagram, TS 120 A.
Komponenter:	Components:
E1-2 Värmebatteri, 2x750W	E1-2 Heater battery, 2x750W
GT1 Termostat 20-45°C (20-60°C)	GT1 Thermostat 20-45°C (20-60°C)
GT3 Termostat, temp.skydd.	GT3 Thermostat, temp. protection.
ÖH1 Överhett.n.skydd.	ÖH1 Overheating protection.
ÖH2 Överhett.n.skydd.	ÖH2 Overheating protection.
K1 Kontaktor, kompressor & fläkt	K1 Contactor, compressor and fan.
K2 Kontaktor, värmebatteri	K2 Contactor, heater battery
K3 Kontektor, överhett.n.skydd	K3 Contactor, overheating protection.
K4 Tidrelä	K4 Time relay
K5 Relä, Dörrkontakt	K5 Relay, Dorr switch
T1 Transformator 12V AC	T1 Transformer 12V AC
M1 Radialfläkt	M1 Fan
+GT2 Termokontakt i fläkt	+GT2 Thermocontact in fan
M2 Kompressor	M2 Compressor
+TK Termokontakt i kompressor	+TK Thermocontact in compressor
S1 Start-knapp	S1 Start button
S2 Stopp-knapp	S2 Stop button
X1 Kopplingsplint	X1 Terminal block